



**GENERAL NOTES:**

1. ANY CEILING, FLOOR, WALL, OR CASEGOOD WORK REQUIRED AS PART OF THIS PROJECT NEEDS TO BE MATCHED WITH EXISTING.

**CODED NOTES:**

- 1 ALL WORK OCCURS IN CRAWL SPACE BELOW FINISHED SPACE.
- 2 PATCH EXISTING NORA RUBBER FLOORING WITH SAME. FLOOR NEEDS TO BE CLEANED AND PREPARED FOR THE TRANSITION TO GENERAL MAINTENANCE ACCORDING TO THE MANUFACTURER'S SPECIFICATION.
- 3 NOT USED
- 4 CUT AND PATCH CONCRETE FLOOR TO REPLACE 4" SANITARY BELOW EXISTING FLOOR SLAB. THIS WORK MUST OCCUR BETWEEN 9:00 P.M. AND 8:00 A.M.
- 5 PROVIDE VISQUEEN DUST BARRIERS, TACKY MATS AT ALL DUST BARRIER ENTRANCES, AND VISQUEEN COVERS OVER ANY HVAC RETURNS WITHIN THE PROJECT AREA. DAILY SWEEP AND CLEAN UP IS REQUIRED.
- 6 PATCH ANY MISSING CERAMIC WALL TILE WITH ATTIC STOCK TILE. GROUT MATCH TO BE APPROVED BY CML.
- 7 PATCH AND BLEND EPOXY FLOOR PAINT SO THAT IS ADHERES AND APPEARS SEAMLESSLY WITH EXISTING.